

# Starlite-V2000 User Manual



## Modify Password for Programming Mode (1.1)

1. Key Default Password #12345
2. Key in New Desire 5 numbers Password Example:  
88888 Re-enter 88888 \* then #\*

New Programming Mode Password Have been Set.

## **Opening Mode**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. Card Only Mode – 300\* #\*
3. Card Or Pin Mode – 301\* #\*
4. Card & Pin Mode – 302\* #\*

## **Add Single Card By Number**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 40# Card Number # \* #\*

Example:

After Enter Programming Mode Key 40#12345678#\* #\*

Card Number of Last 8 Digit From Front Batch of 10 Digit Numbers

## **Add Single Card By Scanning**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 41# Scan Card # \* #\*

## **Add Cards In Batch By Number**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 50# Smallest Card Number # Card Quantities # \* #\*  
Card Numbers MUST Be In Running Sequence

## **Add Cards In Batch By Scanning**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 51# Scan Smallest Card Number & Key Card  
Quantities # \* #\*  
Card Numbers MUST Be In Running Sequence

## **Deleting Single Card By Number**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 60# Card Number # \* #\*

Example:

After Enter Programming Mode Key 60#12345678#\* #\*

Card Number of Last 8 Digit From Front Batch of 10 Digit Numbers

## **Deleting Single Card By Scanning**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 61# Scan Card # \* #\*

## **Deleting Cards In Batch By Number**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 70# Smallest Card Number # Card Quantities # \* #\*  
Card Numbers MUST Be In Running Sequence

## **Deleting Card In Batch By Scanning**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 71# Scan Smallest Card Number & Key Card  
Quantities # \* #\*  
Card Numbers MUST Be In Running Sequence

## **Deleting ALL Cards**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. 888# \* #\*

## **Door Open Duration**

1. Key Default Password #12345 or Modified Password  
(Refer to 1.1)
2. "0" Then (Two Second Digit)

Example:

0 05 for 5 Seconds, 0 08 for 8 Seconds